

Gain Compression Measurements with the SNA Network Analyzer

November 13, 2024

1 Introduction

As the core components of a system, amplifiers are widely used in various RF and microwave systems. Amplifiers have a linear gain region where the input power and output power are linearly related. The gain in this region is referred to as linear gain (also known as small-signal gain). As the input power is increased to a level that causes amplifier to approach saturation, the gain will decrease. The 1 dB gain compression is defined as the input power level that causes amplifier gain to drop 1 dB relative to the linear gain. The gain compression function is to determine the compression power of amplifier at various frequency points within a specified frequency range and to measure the parameters at that point.

2 Compression Definitions

When introducing the compression point in the previous section, it was mentioned that the point where the gain decreases by 1 dB relative to the reference gain is identified as the compression point. The reference gain here refers to the linear gain. However, the selection of the reference gain can vary in different situations. Based on the selection of the reference point, compression can be classified as Compression from Linear Gain, Compression from Max Gain, Compression from Back Off, X/Y Compression, and Compression from Saturation.

Available Compression Methods

<p>Compression from linear gain</p>	<p>The linear gain is measured using the specified linear (input) power level. The compression point is calculated as the linear gain minus the specified compression level.</p>	
<p>Compression from max gain</p>	<p>The highest gain value that is found at each frequency is used as the max gain. The compression point is calculated as the max gain minus the specified compression level.</p>	
<p>Compression from back off</p>	<p>The gains at two input powers that are different with the specified back off level are compared. The compression point is found as the highest input power with the gain difference of the specified compression level.</p>	

[Click to download the whole article.](#)



North American Headquarters

SIGLENT Technologies America, Inc
6557 Cochran Rd Solon, Ohio 44139

Tel: 440-398-5800

Toll Free: 877-515-5551

Fax: 440-399-1211

info@siglent.com

www.siglentamerica.com/

European Sales Offices

SIGLENT TECHNOLOGIES EUROPE GmbH

Staetzlinger Str. 70

86165 Augsburg, Germany

Tel: +49(0)-821-666 0 111 0

Fax: +49(0)-821-666 0 111 22

info-eu@siglent.com

www.siglenteu.com

Asian Headquarters

SIGLENT TECHNOLOGIES CO., LTD.

Blog No.4 & No.5, Antongda Industrial Zone,

3rd Liuxian Road, Bao'an District,

Shenzhen, 518101, China.

Tel: + 86 755 3661 5186

Fax: + 86 755 3359 1582

sales@siglent.com

www.siglent.com/ens